

ECU Pinout

From ECUBEAR

Contents

- 1 Toyota Hilux/Fortuner/Revo
 - 1.1 1GD-FTV, 2GD-FTV (06.2015 - NOW)
 - 1.2 1GR-FE (06.2015 - NOW)
 - 1.3 1KD-FTV, 2KD-FTV AT(06.2015 - NOW)
 - 1.4 5L-E (06.2015 - NOW)
 - 1.5 1TR-FE, 2TR-FE (06.2015 - NOW)
- 2 Toyota Land Cruiser Prado
 - 2.1 1GR-FE (06.2015 - NOW)
 - 2.2 1KD-FTV (06.2015 - 08.2020)
 - 2.3 1GD-FTV (06.2015 - NOW)
 - 2.4 5L-E (06.2015 - NOW)
 - 2.5 2TR-FE (06.2015 - NOW)
- 3 Toyota Land Cruiser / Lexus LX
 - 3.1 1GR-FE (08.2015 - 08.2017)
 - 3.2 1GR-FE (08.2017 - NOW)
 - 3.3 1UR-FE (08.2014 - NOW)
 - 3.4 3UR-FE (08.2015 - NOW)
 - 3.5 1VD-FTV (08.2014 - NOW)
- 4 Toyota Prius
 - 4.1 ZVW50 2ZR-FXE (11.2015 - NOW)
 - 4.2 Prius ZVW30 2ZR-FXE (2009 - 2015),Prius Plus ZVW40 2ZR-FXE (2012 - NOW)
- 5 Toyota Alphard/Veilifire
 - 5.1 Alphard 2AR-FE AGH30 (2015 - 2019)
 - 5.2 Alphard 2GR-FE GGH30 (2015 - NOW)
 - 5.3 Alphard 2GR-FKS GGH30 (2015 - NOW)

Toyota Hilux/Fortuner/Revo

1GD-FTV, 2GD-FTV (06.2015 - NOW)

C57


C58

C59

C60

G85

G86



Y

G86-5 (E1)	G85-1 (BATT)	G85-4 (+B) G85-3 (+B2) G85-2 (+B3) G86-18 (IGSW)	G85-17 (CANH) G85-28 (CANL)
Ground	Constant power	Switched power	Communication

1GR-FE (06.2015 - NOW)

G87


G88

C15

C14

C13

C12



C13-12 (E1)	G87-24 (BATT)	G87-23 (+B) G87-22 (+B2) G87-21 (IGSW)	G88-31 (CANH) G88-25 (CANL)
Ground	Constant power	Switched power	Communication


1KD-FTV, 2KD-FTV AT(06.2015 - NOW)

C55

C56

G83

G84



C56-7 (E1)	G83-2 (BATT)	G84-1 (+B) G84-9 (IGSW)	G83-22 (CANH) G83-21 (CANL)
Ground	Constant power	Switched power	Communication


5L-E (06.2015 - NOW)

C127

C128

G120

G121




Y

A66714


C127-5 (E1)	G121-2 (BATT)	G121-1 (+B) G121-11 (IGSW)	G121-25 (CANH) G121-31 (CANL)
Ground	Constant power	Switched power	Communication

1TR-FE, 2TR-FE (06.2015 - NOW)

*A



*B




- A - for Automatic Transmission Models
- B - for Manual Transmission Models

C52-3 (E1)	G46-3 (BATT)	G46-1 (+B) G46-2 (+B2) G46-8 (IGSW)	G45-13 (CANH) G45-14 (CANL)
Ground	Constant power	Switched power	Communication


Toyota Land Cruiser Prado

1GR-FE (06.2015 - NOW)




C36-12 (E1)	G55-24 (BATT)	G55-23 (+B) G55-22 (+B2) G55-21 (IGSW)	G56-31 (CANH) G56-25 (CANL)
Ground	Constant power	Switched power	Communication

1KD-FTV (06.2015 - 08.2020)




C93-1 (E1)	G57-23 (BATT)	G57-24 (+B) G57-17 (+B2) G58-24 (IGSW)	G58-35 (CANH) G58-36 (CANL)
Ground	Constant power	Switched power	Communication

1GD-FTV (06.2015 - NOW)



G185-5 (E1)	G184-1 (BATT)	G184-4 (+B) G184-3 (+B2) G184-2 (+B3) G185-18 (IGSW)	G184-17 (CANH) G184-28 (CANL)
Ground	Constant power	Switched power	Communication

5L-E (06.2015 - NOW)




Y

A66714

C161-5 (E1)	G183-2 (BATT)	G183-1 (+B) G183-11 (IGSW)	G183-25 (CANH) G183-31 (CANL)
Ground	Constant power	Switched power	Communication

2TR-FE (06.2015 - NOW)




- A - for Automatic Transmission Models

- B - for Manual Transmission Models

C153-3 (E1)	G180-3 (BATT)	G180-1 (+B) G180-2 (+B2) G180-8 (IGSW)	G181-13 (CANH) G181-14 (CANL)
Ground	Constant power	Switched power	Communication

Toyota Land Cruiser / Lexus LX

1GR-FE (08.2015 - 08.2017)




*1: for LHD

*2: for RHD

C45*1-81 (E1) C46*2-81 (E1)	A38*1-1 (BATT) A52*2-1 (BATT)	A38*1-3 (+B) A52*2-3 (+B) A38*1-2 (+B2) A52*2-2 (+B2) A38*1-28 (IGSW) A52*2-28 (IGSW)	A38*1-10 (CANH) A52*2-10 (CANH) A38*1-11 (CANL) A52*2-11 (CANL)
Ground	Constant power	Switched power	Communication

1GR-FE (08.2017 - NOW)




*1: for LHD

*2: for RHD

C45-81 (E1)	A38-1 (BATT)	A38-3 (+B) A38-2 (+B2) A38-28 (IGSW)	A38-11 (CANH) A38-19 (CANL)
Ground	Constant power	Switched power	Communication

1UR-FE (08.2014 - NOW)




*1: for RHD

*2: for LHD


C46*1-81 (E1) C45*2-81 (E1)	A38*2-1 (BATT) A52*1-1 (BATT)	A38*2-3 (+B) A52*1-3 (+B) A38*2-2 (+B2) A52*1-2 (+B2) A38*2-28 (IGSW) A52*1-28 (IGSW)	A38*2-10 (CANH) A52*1-10 (CANH) A38*2-11 (CANL) A52*1-11 (CANL)
Ground	Constant power	Switched power	Communication

3UR-FE (08.2015 - NOW)



C45-81 (E1)	A38-1 (BATT)	A38-2 (+B) A38-3 (+B2) A38-4 (IGSW)	A38-11 (CANH) A38-19 (CANL)
Ground	Constant power	Switched power	Communication

1VD-FTV (08.2014 - NOW)




*1: for LHD

*2: for RHD

C45*1-81 (E1) C46*2-81 (E1)	A38*1-20 (BATT) A52*2-20 (BATT)	A38*1-1 (+B) A52*2-1 (+B) A38*1-2 (+B2) A52*2-2 (+B2) A38*1-28 (IGSW) A52*2-28 (IGSW)	A38*1-41 (CANH) A52*2-41 (CANH) A38*1-49 (CANL) A52*2-49 (CANL)
Ground	Constant power	Switched power	Communication


Toyota Prius

ZVW50 2ZR-FXE (11.2015 - NOW)




C31-59 (E1)	A40-1 (BATT)	A40-2 (+B) A40-3 (+B2) A40-6 (IGSW)	A40-13 (CANH) A40-26 (CANL)
Ground	Constant power	Switched power	Communication

Prius ZVW30 2ZR-FXE (2009 - 2015),
Prius Plus ZVW40 2ZR-FXE (2012 - NOW)




D28-104 (E1)	A57-20 (BATT)	A57-2 (+B) A57-1 (+B2) A57-28 (IGSW)	A57-13 (CANH) A57-5 (CANL)
Ground	Constant power	Switched power	Communication

Toyota Alphard/Veilfire
Alphard 2AR-FE AGH30 (2015 - 2019)




D1-59 (E1)	A53-1 (BATT)	A53-2 (+B) A53-3 (+B2) A53-6 (IGSW)	A53-13 (CANH) A53-26 (CANL)
Ground	Constant power	Switched power	Communication

Alphard 2GR-FE GGH30 (2015 - NOW)



D1-49 (E1)	A53-1 (BATT)	A53-2 (+B) A53-3 (+B2) A53-32 (IGSW)	A53-13 (CANH) A53-26 (CANL)
Ground	Constant power	Switched power	Communication

Alphard 2GR-FKS GGH30 (2015 - NOW)



D1-53 (E1)	A53-1 (BATT)	A53-2 (+B) A53-3 (+B2) A53-4 (IGSW)	A53-13 (CANH) A53-26 (CANL)
Ground	Constant power	Switched power	Communication